



グリル用調理容器対応表 - ビルトインタイププリンナイ製 (RHシリーズ) ガスコンロをお使いの方
お手持ちのコンロ製品型番 先頭の英数字を下記からお調べください。対応するグリル用調理容器をご確認いただけます。

コンロ型番	浅型プレート											深型鍋			
	グリル用プレート											ダッチオーブン		ココット ダッチオーブン	
コンロ型番	RCP-71W	RCP-73V	RCP-72V	RCP-74W	RCP-80W	RCP-81W	RCP-65V	RCP-48V	RCP-60M	RBO-C1V	RBO-C2V	RDH-01V	RDH-02V	RBO-D1V	RBO-D2V
RHB21W14K12R-VL	-	-	-	-	-	-	○	-	-	-	-	-	-	-	-
RHB21W14S8R-VL	-	-	-	-	-	-	○	-	-	-	-	-	-	-	-
RHB21W9K12R-VL	-	-	-	-	-	-	○	-	-	-	-	-	-	-	-
RHB21W9S8R-VL	-	-	-	-	-	-	○	-	-	-	-	-	-	-	-
RHB721W14S8R-VL	-	-	-	-	-	-	○	-	-	-	-	-	-	-	-
RHB721W9S8R-VL	-	-	-	-	-	-	○	-	-	-	-	-	-	-	-
RHS21W4D8V2-SL	○	-	○	○	-	-	-	-	-	-	-	-	-	-	-
RHS21W4D8V2-SR	○	-	○	○	-	-	-	-	-	-	-	-	-	-	-
RHS21W4D8VSL	○	-	○	○	-	-	-	-	-	-	-	-	-	-	-
RHS21W4D8VSL(S)	○	-	○	○	-	-	-	-	-	-	-	-	-	-	-
RHS21W4D8VSR	○	-	○	○	-	-	-	-	-	-	-	-	-	-	-
RHS21W4D8VSR(S)	○	-	○	○	-	-	-	-	-	-	-	-	-	-	-
RHS21W8K12T-VL	-	-	-	-	-	-	○	-	-	-	-	-	-	-	-
RHS21W8K12T-VR	-	-	-	-	-	-	○	-	-	-	-	-	-	-	-
RHS21W9S8R-VL	-	-	-	-	-	-	○	-	-	-	-	-	-	-	-
RHS21W9S8R-VR	-	-	-	-	-	-	○	-	-	-	-	-	-	-	-
RHS31W10G11R-BL	○	○	-	○	-	-	-	-	-	-	-	-	○	-	-
RHS31W10G11R-BR	○	○	-	○	-	-	-	-	-	-	-	-	○	-	-
RHS31W10G12R-SL	○	○	-	○	-	-	-	-	-	-	-	-	○	-	-
RHS31W10G12R-SR	○	○	-	○	-	-	-	-	-	-	-	-	○	-	-
RHS31W10G7R-SL	○	○	-	○	-	-	-	-	-	-	-	-	○	-	-
RHS31W10G7R-SR	○	○	-	○	-	-	-	-	-	-	-	-	○	-	-
RHS31W10G8R-SL	○	○	-	○	-	-	-	-	-	-	-	-	○	-	-
RHS31W10G8R-SR	○	○	-	○	-	-	-	-	-	-	-	-	○	-	-
RHS31W11G14R-SL	-	-	-	-	-	-	○	-	-	-	-	-	-	-	-
RHS31W11G14R-SR	-	-	-	-	-	-	○	-	-	-	-	-	-	-	-
RHS31W13A17R-VL	-	-	-	-	-	-	○	-	-	-	-	-	-	-	-
RHS31W13A17R-VR	-	-	-	-	-	-	○	-	-	-	-	-	-	-	-
RHS31W8A2R-VL	-	-	-	-	-	-	○	-	-	-	-	-	-	-	-
RHS31W8A2R-VR	-	-	-	-	-	-	○	-	-	-	-	-	-	-	-
RHS31WG7R2-SL	○	-	○	○	-	-	-	-	-	-	-	○	-	-	-
RHS31WG7R2-SR	○	-	○	○	-	-	-	-	-	-	-	○	-	-	-
RHS71W10G11R-BL	○	○	-	○	-	-	-	-	-	-	-	-	○	-	-
RHS71W10G11R-BR	○	○	-	○	-	-	-	-	-	-	-	-	○	-	-
RHS71W10G12R-SL	○	○	-	○	-	-	-	-	-	-	-	-	○	-	-
RHS71W10G12R-SR	○	○	-	○	-	-	-	-	-	-	-	-	○	-	-
RHS71W10G12V-SL	○	○	-	○	-	-	-	-	-	-	-	-	○	-	-
RHS71W10G12V-SR	○	○	-	○	-	-	-	-	-	-	-	-	○	-	-
RHS71W10G7R-SL	○	○	-	○	-	-	-	-	-	-	-	-	○	-	-
RHS71W10G7V-SL	○	○	-	○	-	-	-	-	-	-	-	-	○	-	-
RHS71W10G7V-SR	○	○	-	○	-	-	-	-	-	-	-	-	○	-	-
RHS71W10G8R-SL	○	○	-	○	-	-	-	-	-	-	-	-	○	-	-
RHS71W10G8R-SR	○	○	-	○	-	-	-	-	-	-	-	-	○	-	-
RHS71W10G8V-SL	○	○	-	○	-	-	-	-	-	-	-	-	○	-	-
RHS71W10G8V-SR	○	○	-	○	-	-	-	-	-	-	-	-	○	-	-



グリル用調理容器対応表 - ビルトインタイププリンナイ製 (RHシリーズ) ガスコンロをお使いの方
お手持ちのコンロ製品型番 先頭の英数字を下記からお調べください。対応するグリル用調理容器をご確認いただけます。

コンロ型番	浅型プレート											深型鍋			
	グリル用プレート											ダッチオーブン		ココット ダッチオーブン	
	RCP-71W	RCP-73V	RCP-72V	RCP-74W	RCP-80W	RCP-81W	RCP-65V	RCP-48V	RCP-60M	RBO-C1V	RBO-C2V	RDH-01V	RDH-02V	RBO-D1V	RBO-D2V
RHS71W10G9V-BL	○	○	-	○	-	-	-	-	-	-	-	-	○	-	-
RHS71W10G9V-BR	○	○	-	○	-	-	-	-	-	-	-	-	○	-	-
RHS71W11G14R-SL	-	-	-	-	-	-	○	-	-	-	-	-	-	-	-
RHS71W11G14R-SR	-	-	-	-	-	-	○	-	-	-	-	-	-	-	-
RHS71W13A17R-VL	-	-	-	-	-	-	○	-	-	-	-	-	-	-	-
RHS71W13A17R-VR	-	-	-	-	-	-	○	-	-	-	-	-	-	-	-
RHS71W8A2R-VL	-	-	-	-	-	-	○	-	-	-	-	-	-	-	-
RHS71W8A2R-VR	-	-	-	-	-	-	○	-	-	-	-	-	-	-	-
RHS71WG7R2-SL	○	-	○	○	-	-	-	-	-	-	-	○	-	-	-
RHS71WG7R2-SR	○	-	○	○	-	-	-	-	-	-	-	○	-	-	-
RHS71WG7V2-SL	○	-	○	○	-	-	-	-	-	-	-	○	-	-	-
RHS71WG7V2-SR	○	-	○	○	-	-	-	-	-	-	-	○	-	-	-
RHS71WG7VSL	○	-	○	○	-	-	-	-	-	-	-	-	-	-	-
RHS71WG7VSR	○	-	○	○	-	-	-	-	-	-	-	-	-	-	-
RHS71WG8V2-SL	○	-	○	○	-	-	-	-	-	-	-	○	-	-	-
RHS71WG8V2-SR	○	-	○	○	-	-	-	-	-	-	-	○	-	-	-
RHS71WG8VSL	○	-	○	○	-	-	-	-	-	-	-	-	-	-	-
RHS71WG8VSR	○	-	○	○	-	-	-	-	-	-	-	-	-	-	-
RHS71WG9V2-BL	○	-	○	○	-	-	-	-	-	-	-	○	-	-	-
RHS71WG9V2-BR	○	-	○	○	-	-	-	-	-	-	-	○	-	-	-
RHS721W9S8R-VL	-	-	-	-	-	-	○	-	-	-	-	-	-	-	-
RHS721W9S8R-VR	-	-	-	-	-	-	○	-	-	-	-	-	-	-	-
RHS21W14S8R-VL	-	-	-	-	-	-	○	-	-	-	-	-	-	-	-
RHS21W14S8R-VR	-	-	-	-	-	-	○	-	-	-	-	-	-	-	-
RHS31W13A16D2-VW	-	-	-	-	-	-	○	-	-	-	-	-	-	-	-
RHS31W15G11R-BW	○	○	-	○	-	-	-	-	-	-	-	-	○	-	-
RHS31W15G23R-STW	○	○	-	○	-	-	-	-	-	-	-	-	○	-	-
RHS31W15G7R-STW	○	○	-	○	-	-	-	-	-	-	-	-	○	-	-
RHS31W15G8R-STW	○	○	-	○	-	-	-	-	-	-	-	-	○	-	-
RHS31WG16RX4-SL	○	-	○	○	-	-	-	-	-	-	-	-	-	-	-
RHS31WG16RX4-SR	○	-	○	○	-	-	-	-	-	-	-	-	-	-	-
RHS71W15G11R-BW	○	○	-	○	-	-	-	-	-	-	-	-	○	-	-
RHS71W15G23R-STW	○	○	-	○	-	-	-	-	-	-	-	-	○	-	-
RHS71W15G23V-STW	○	○	-	○	-	-	-	-	-	-	-	-	○	-	-
RHS71W15G7R-STW	○	○	-	○	-	-	-	-	-	-	-	-	○	-	-
RHS71W15G7V-STW	○	○	-	○	-	-	-	-	-	-	-	-	○	-	-
RHS71W15G8R-STW	○	○	-	○	-	-	-	-	-	-	-	-	○	-	-
RHS71W15G8V-STW	○	○	-	○	-	-	-	-	-	-	-	-	○	-	-
RHS71W15G9V-BW	○	○	-	○	-	-	-	-	-	-	-	-	○	-	-
RHS71WG16RX4-SL	○	-	○	○	-	-	-	-	-	-	-	-	-	-	-
RHS71WG16RX4-SR	○	-	○	○	-	-	-	-	-	-	-	-	-	-	-
RHS721W14S8R-VL	-	-	-	-	-	-	○	-	-	-	-	-	-	-	-
RHS721W14S8R-VR	-	-	-	-	-	-	○	-	-	-	-	-	-	-	-
RHX31W13A18R-VL	-	-	-	-	-	-	○	-	-	-	-	-	-	-	-
RHX31W13A18R-VR	-	-	-	-	-	-	○	-	-	-	-	-	-	-	-



グリル用調理容器対応表 - ビルトインタイプリンナイ製 (RHシリーズ) ガスコンロをお使いの方
お手持ちのコンロ製品型番 先頭の英数字を下記からお調べください。対応するグリル用調理容器をご確認いただけます。

コンロ型番	浅型プレート											深型鍋			
	グリル用プレート											ダッチオープン		ココット ダッチオープン	
	RCP-71W	RCP-73V	RCP-72V	RCP-74W	RCP-80W	RCP-81W	RCP-65V	RCP-48V	RCP-60M	RBO-C1V	RBO-C2V	RDH-01V	RDH-02V	RBO-D1V	RBO-D2V
RHS31W17G24R-STW	○	○	-	○	○	-	-	-	-	-	-	-	-	-	-
RHS31W17G11R-STW	○	○	-	○	○	-	-	-	-	-	-	-	-	-	-
RHS31W19G27R-STW	○	○	-	○	○	-	-	-	-	-	-	-	-	-	-
RHS71W19G27R-STW	○	○	-	○	○	-	-	-	-	-	-	-	-	-	-
RHS71W17G26R-STW	○	○	-	○	○	-	-	-	-	-	-	-	-	-	-
RHS71W17G25R-STW	○	○	-	○	○	-	-	-	-	-	-	-	-	-	-
RHS71W17G24R-STW	○	○	-	○	○	-	-	-	-	-	-	-	-	-	-
RHS31W17G26R-STW	○	○	-	○	○	-	-	-	-	-	-	-	-	-	-
RHS31W17G25R-STW	○	○	-	○	○	-	-	-	-	-	-	-	-	-	-
RHS71W17G11R-STW	○	○	-	○	○	-	-	-	-	-	-	-	-	-	-
RHS71W12G16RX-SL	-	-	-	-	-	-	○	-	-	-	-	-	-	-	-
RHS71W12G16RX-SR	-	-	-	-	-	-	○	-	-	-	-	-	-	-	-
RHS31W12G16RX-SL	-	-	-	-	-	-	○	-	-	-	-	-	-	-	-
RHS31W12G16RX-SR	-	-	-	-	-	-	○	-	-	-	-	-	-	-	-
RHS71W16ALR-SL	○	○	-	○	-	-	-	-	○	-	-	-	-	○	-
RHS71W16ALR-SR	○	○	-	○	-	-	-	-	○	-	-	-	-	○	-
RHB71W16ALR-SL	○	○	-	○	-	-	-	-	○	-	-	-	-	○	-
RHS71W15G7V3-STW	○	○	-	○	○	-	-	-	○	-	-	-	-	○	-
RHS71W15G8V3-STW	○	○	-	○	○	-	-	-	○	-	-	-	-	○	-
RHS71W15G23V3-STW	○	○	-	○	○	-	-	-	○	-	-	-	-	○	-
RHS71W15G22V3-STW	○	○	-	○	○	-	-	-	○	-	-	-	-	○	-
RHS71W15G9V3-BW	○	○	-	○	○	-	-	-	○	-	-	-	-	○	-
RHS31W15G7R3-STW	○	○	-	○	○	-	-	-	○	-	-	-	-	○	-
RHS31W15G8R3-STW	○	○	-	○	○	-	-	-	○	-	-	-	-	○	-
RHS31W15G11R3-BW	○	○	-	○	○	-	-	-	○	-	-	-	-	○	-
RHS31W15G22R3-STW	○	○	-	○	○	-	-	-	○	-	-	-	-	○	-
RHS31W15G23R3-STW	○	○	-	○	○	-	-	-	○	-	-	-	-	○	-
RHS71W15G7R3-STW	○	○	-	○	○	-	-	-	○	-	-	-	-	○	-
RHS71W15G8R3-STW	○	○	-	○	○	-	-	-	○	-	-	-	-	○	-
RHS71W15G11R3-BW	○	○	-	○	○	-	-	-	○	-	-	-	-	○	-
RHS71W15G22R3-STW	○	○	-	○	○	-	-	-	○	-	-	-	-	○	-
RHS71W15G23R3-STW	○	○	-	○	○	-	-	-	○	-	-	-	-	○	-
RHS71W15G23V3C-STW	○	○	-	○	○	-	-	-	○	-	-	-	-	○	-
RHS71W15G22V3C-STW	○	○	-	○	○	-	-	-	○	-	-	-	-	○	-
RHS71W15G7V3C-STW	○	○	-	○	○	-	-	-	○	-	-	-	-	○	-
RHS71W15G8V3C-STW	○	○	-	○	○	-	-	-	○	-	-	-	-	○	-
RHS71W15G9V3C-BW	○	○	-	○	○	-	-	-	○	-	-	-	-	○	-
RHS71W15G23R3C-STW	○	○	-	○	○	-	-	-	○	-	-	-	-	○	-
RHS31W15G23R3C-STW	○	○	-	○	○	-	-	-	○	-	-	-	-	○	-
RHS71W15G22R3C-STW	○	○	-	○	○	-	-	-	○	-	-	-	-	○	-
RHS31W15G22R3C-STW	○	○	-	○	○	-	-	-	○	-	-	-	-	○	-
RHS71W15G7R3C-STW	○	○	-	○	○	-	-	-	○	-	-	-	-	○	-
RHS31W15G7R3C-STW	○	○	-	○	○	-	-	-	○	-	-	-	-	○	-
RHB71W21A30D2-VW	-	-	-	-	-	-	○	-	-	-	-	-	-	-	-
RHB71W21B33D2-VW	-	-	-	-	-	-	○	-	-	-	-	-	-	-	-



グリル用調理容器対応表 - ビルトインタイプリンナイ製 (RHシリーズ) ガスコンロをお使いの方
 お手持ちのコンロ製品型番 先頭の英数字を下記からお調べください。対応するグリル用調理容器をご確認いただけます。

コンロ型番	浅型プレート											深型鍋			
	グリル用プレート											ダッチオープン		ココット ダッチオープン	
コンロ型番	RCP-71W	RCP-73V	RCP-72V	RCP-74W	RCP-80W	RCP-81W	RCP-65V	RCP-48V	RCP-60M	RBO-C1V	RBO-C2V	RDH-01V	RDH-02V	RBO-D1V	RBO-D2V
RHB31W21A30D2-VW	-	-	-	-	-	-	○	-	-	-	-	-	-	-	-
RHB71AW21A30R2-VM	-	-	-	-	-	-	○	-	-	-	-	-	-	-	-
RHB71AW21B33R2-VW	-	-	-	-	-	-	○	-	-	-	-	-	-	-	-
RHB31AW21A30R2-VW	-	-	-	-	-	-	○	-	-	-	-	-	-	-	-
RHB31AW21B33R2-VW	-	-	-	-	-	-	○	-	-	-	-	-	-	-	-
RHS72W22E2RC-STW	-	-	-	○	○	-	-	-	-	-	○	-	-	-	○
RHS31W22E3RC-STW	-	-	-	○	○	-	-	-	-	-	○	-	-	-	○
RHS71W22E1RC-BW	-	-	-	○	○	-	-	-	-	-	○	-	-	-	○
RHS71W22E3R-STW	-	-	-	○	○	-	-	-	-	-	○	-	-	-	○
RHS72W22E6VC-STW	-	-	-	○	○	-	-	-	-	-	○	-	-	-	○
RHS31W22E4RC-STW	-	-	-	○	○	-	-	-	-	-	○	-	-	-	○
RHS72W22E2VC-STW	-	-	-	○	○	-	-	-	-	-	○	-	-	-	○
RHS31W22E4R-STW	-	-	-	○	○	-	-	-	-	-	○	-	-	-	○
RHS31W22E3R-STW	-	-	-	○	○	-	-	-	-	-	○	-	-	-	○
RHS71W22E4VC-STW	-	-	-	○	○	-	-	-	-	-	○	-	-	-	○
RHS71W22E5VC-BW	-	-	-	○	○	-	-	-	-	-	○	-	-	-	○
RHS71W22E1R-BW	-	-	-	○	○	-	-	-	-	-	○	-	-	-	○
RHS31W22E1RC-BW	-	-	-	○	○	-	-	-	-	-	○	-	-	-	○
RHS72W22E4RC-STW	-	-	-	○	○	-	-	-	-	-	○	-	-	-	○
RHS72W22E5VC-BW	-	-	-	○	○	-	-	-	-	-	○	-	-	-	○
RHS71W22E3RC-STW	-	-	-	○	○	-	-	-	-	-	○	-	-	-	○
RHS32W22E3RC-STW	-	-	-	○	○	-	-	-	-	-	○	-	-	-	○
RHS71W22E4RC-STW	-	-	-	○	○	-	-	-	-	-	○	-	-	-	○
RHS31W22E2R-STW	-	-	-	○	○	-	-	-	-	-	○	-	-	-	○
RHS71W22E4R-STW	-	-	-	○	○	-	-	-	-	-	○	-	-	-	○
RHS71W22E2R-STW	-	-	-	○	○	-	-	-	-	-	○	-	-	-	○
RHS72W22E4VC-STW	-	-	-	○	○	-	-	-	-	-	○	-	-	-	○
RHS32W22E4RC-STW	-	-	-	○	○	-	-	-	-	-	○	-	-	-	○
RHS72W22E6RC-STW	-	-	-	○	○	-	-	-	-	-	○	-	-	-	○
RHS71W22E3VC-STW	-	-	-	○	○	-	-	-	-	-	○	-	-	-	○
RHS71W22E6VC-STW	-	-	-	○	○	-	-	-	-	-	○	-	-	-	○
RHS32W22E2RC-STW	-	-	-	○	○	-	-	-	-	-	○	-	-	-	○
RHS72W22E3RC-STW	-	-	-	○	○	-	-	-	-	-	○	-	-	-	○
RHS72W22E3VC-STW	-	-	-	○	○	-	-	-	-	-	○	-	-	-	○
RHS31W22E1R-BW	-	-	-	○	○	-	-	-	-	-	○	-	-	-	○
RHS71W22E2VC-STW	-	-	-	○	○	-	-	-	-	-	○	-	-	-	○
RHS31W22E2RC-STW	-	-	-	○	○	-	-	-	-	-	○	-	-	-	○
RHS32W22E6RC-STW	-	-	-	○	○	-	-	-	-	-	○	-	-	-	○
RHS71W22E2RC-STW	-	-	-	○	○	-	-	-	-	-	○	-	-	-	○