



グリル用調理容器対応表 - ビルトインタイプリンナイ製(RRシリーズ)ガスコンロをお使いの方
お手持ちのコンロ製品型番 先頭の英数字を下記からお調べください。対応するグリル用調理容器をご確認いただけます。

コンロ型番	浅型プレート											深型鍋			
	グリル用プレート									ココット		ダッチオーブン		ココット ダッチオーブン	
RCP-71W	RCP-73V	RCP-72V	RCP-74W	RCP-80W	RCP-81W	RCP-65V	RCP-48V	RCP-60M	RBO-C1V	RBO-C2V	RDH-01V	RDH-02V	RBO-D1V	RBO-D2V	
RR31WG1RSL	○	-	○	○	-	-	-	-	-	-	-	-	-	-	-
RR71WG1RSL	○	-	○	○	-	-	-	-	-	-	-	-	-	-	-
RR71WG7RSL	○	-	○	○	-	-	-	-	-	-	-	-	-	-	-
RR7W10G7RSL	○	○	-	○	-	-	-	-	-	-	-	○	-	-	-
RRB21W4D8V2-SL	○	-	○	○	-	-	-	-	-	-	-	-	-	-	-
RRB21W4D8VSL	○	-	○	○	-	-	-	-	-	-	-	-	-	-	-
RRB31AW13A16R-VW	-	-	-	-	-	-	○	-	-	-	-	-	-	-	-
RRB31AW13B1R-VW	-	-	-	-	-	-	○	-	-	-	-	-	-	-	-
RRB31AW3A2R2-VL	-	-	-	-	-	-	○	-	-	-	-	-	-	-	-
RRB31AW8A2R-VL	-	-	-	-	-	-	○	-	-	-	-	-	-	-	-
RRB31AW8B1R-VL	-	-	-	-	-	-	○	-	-	-	-	-	-	-	-
RRB31W10G11R-SL	○	○	-	○	-	-	-	-	-	-	-	-	○	-	-
RRB31W10G12R-SL	○	○	-	○	-	-	-	-	-	-	-	-	○	-	-
RRB31W10G7R-SL	○	○	-	○	-	-	-	-	-	-	-	-	○	-	-
RRB31W12A10R-SL	-	-	-	-	-	-	○	-	-	-	-	-	-	-	-
RRB31W12A10R-SR	-	-	-	-	-	-	○	-	-	-	-	-	-	-	-
RRB31W12B1R-SL	-	-	-	-	-	-	○	-	-	-	-	-	-	-	-
RRB31W13A16D-VW	-	-	-	-	-	-	○	-	-	-	-	-	-	-	-
RRB31W2B1RVL	-	-	-	-	-	-	○	-	-	-	-	-	-	-	-
RRB31W7A10R-VL	-	-	-	-	-	-	○	-	-	-	-	-	-	-	-
RRB31W7A2R-VL	-	-	-	-	-	-	○	-	-	-	-	-	-	-	-
RRB31W8A2D-VL	-	-	-	-	-	-	○	-	-	-	-	-	-	-	-
RRB31W8B1D-BL	-	-	-	-	-	-	○	-	-	-	-	-	-	-	-
RRB31WG1RSL	○	-	○	○	-	-	-	-	-	-	-	-	-	-	-
RRB31WG5RSL	○	-	○	○	-	-	-	-	-	-	-	-	-	-	-
RRB31WG7RSL	○	-	○	○	-	-	-	-	-	-	-	-	-	-	-
RRB71AW13A16R-VW	-	-	-	-	-	-	○	-	-	-	-	-	-	-	-
RRB71AW13B1R-VW	-	-	-	-	-	-	○	-	-	-	-	-	-	-	-
RRB71AW3A2R2-VL	-	-	-	-	-	-	○	-	-	-	-	-	-	-	-
RRB71AW8A2R-VL	-	-	-	-	-	-	○	-	-	-	-	-	-	-	-
RRB71AW8B1R-VL	-	-	-	-	-	-	○	-	-	-	-	-	-	-	-
RRB71W10G	○	○	-	○	-	-	-	-	-	-	-	-	○	-	-
RRB71W10G11R-SL	○	○	-	○	-	-	-	-	-	-	-	-	○	-	-
RRB71W10G12R-SL	○	○	-	○	-	-	-	-	-	-	-	-	○	-	-
RRB71W10G7R-SL	○	○	-	○	-	-	-	-	-	-	-	-	○	-	-
RRB71W10G7R-SR	○	○	-	○	-	-	-	-	-	-	-	-	○	-	-
RRB71W10G7V-SL	○	○	-	○	-	-	-	-	-	-	-	-	○	-	-
RRB71W10G7VSLCK	○	○	-	○	-	-	-	-	-	-	-	-	○	-	-
RRB71W10G7V-SR	○	○	-	○	-	-	-	-	-	-	-	-	○	-	-
RRB71W10G7VSRCK	○	○	-	○	-	-	-	-	-	-	-	-	○	-	-
RRB71W12A10R-SL	-	-	-	-	-	-	○	-	-	-	-	-	-	-	-
RRB71W12A10RSLC	-	-	-	-	-	-	○	-	-	-	-	-	-	-	-
RRB71W12A10R-SR	-	-	-	-	-	-	○	-	-	-	-	-	-	-	-
RRB71W12A10RSRC	-	-	-	-	-	-	○	-	-	-	-	-	-	-	-
RRB71W12B1R-SL	-	-	-	-	-	-	○	-	-	-	-	-	-	-	-



グリル用調理容器対応表 - ビルトインタイププリンナイ製 (RRシリーズ) ガスコンロをお使いの方
お手持ちのコンロ製品型番 先頭の英数字を下記からお調べください。対応するグリル用調理容器をご確認いただけます。

コンロ型番	浅型プレート											深型鍋			
	グリル用プレート									ココット		ダッチオーブン		ココット ダッチオーブン	
コンロ型番	RCP-71W	RCP-73V	RCP-72V	RCP-74W	RCP-80W	RCP-81W	RCP-65V	RCP-48V	RCP-60M	RBO-C1V	RBO-C2V	RDH-01V	RDH-02V	RBO-D1V	RBO-D2V
RRB71W13A16D-VW	-	-	-	-	-	-	○	-	-	-	-	-	-	-	-
RRB71W2A2RVHMLC	-	-	-	-	-	-	○	-	-	-	-	-	-	-	-
RRB71W2A2RVHMRC	-	-	-	-	-	-	○	-	-	-	-	-	-	-	-
RRB71W2A2RVL	-	-	-	-	-	-	○	-	-	-	-	-	-	-	-
RRB71W2A2RVLC	-	-	-	-	-	-	○	-	-	-	-	-	-	-	-
RRB71W2A2RVRC	-	-	-	-	-	-	○	-	-	-	-	-	-	-	-
RRB71W2B1RBL	-	-	-	-	-	-	○	-	-	-	-	-	-	-	-
RRB71W2B1RVL	-	-	-	-	-	-	○	-	-	-	-	-	-	-	-
RRB71W5ALRSL	○	-	○	○	-	-	-	-	-	-	-	○	-	-	-
RRB71W5ALRSLC	○	-	○	○	-	-	-	-	-	-	-	○	-	-	-
RRB71W7A10R-VL	-	-	-	-	-	-	○	-	-	-	-	-	-	-	-
RRB71W7A2R-VL	-	-	-	-	-	-	○	-	-	-	-	-	-	-	-
RRB71W7A2R-VLC	-	-	-	-	-	-	○	-	-	-	-	-	-	-	-
RRB71W7A2RVLCHM	-	-	-	-	-	-	○	-	-	-	-	-	-	-	-
RRB71W7A2RVLCK	-	-	-	-	-	-	○	-	-	-	-	-	-	-	-
RRB71W7A2R-VRC	-	-	-	-	-	-	○	-	-	-	-	-	-	-	-
RRB71W7A2RVRCHM	-	-	-	-	-	-	○	-	-	-	-	-	-	-	-
RRB71W7A2RVRCCK	-	-	-	-	-	-	○	-	-	-	-	-	-	-	-
RRB71W8A2D-VL	-	-	-	-	-	-	○	-	-	-	-	-	-	-	-
RRB71W8B1D-BL	-	-	-	-	-	-	○	-	-	-	-	-	-	-	-
RRB71WG1RSL	○	-	○	○	-	-	-	-	-	-	-	-	-	-	-
RRB71WG5RSL	○	-	○	○	-	-	-	-	-	-	-	-	-	-	-
RRB71WG7RSL	○	-	○	○	-	-	-	-	-	-	-	-	-	-	-
RRB71WG7V2-SL	○	-	○	○	-	-	-	-	-	-	-	○	-	-	-
RRB71WG7V2-SR	○	-	○	○	-	-	-	-	-	-	-	○	-	-	-
RRB71WG7V-SL	○	-	○	○	-	-	-	-	-	-	-	-	-	-	-
RRB71WG7V-SR	○	-	○	○	-	-	-	-	-	-	-	-	-	-	-
RRB71WG9V2-BL	○	-	○	○	-	-	-	-	-	-	-	○	-	-	-
RRB71WG9V2-BR	○	-	○	○	-	-	-	-	-	-	-	○	-	-	-
RRS38W7G10R-VL	-	-	-	-	-	-	○	-	-	-	-	-	-	-	-
RRS38W7G10R-VR	-	-	-	-	-	-	○	-	-	-	-	-	-	-	-
RRS78W7G10R-VL	-	-	-	-	-	-	○	-	-	-	-	-	-	-	-
RRS78W7G10R-VR	-	-	-	-	-	-	○	-	-	-	-	-	-	-	-
RRB31AWB1RX3-SL	-	-	-	-	-	-	○	-	-	-	-	-	-	-	-
RRB31W15G11R-STW	○	○	-	○	-	-	-	-	-	-	-	-	○	-	-
RRB31W15G23R-STW	○	○	-	○	-	-	-	-	-	-	-	-	○	-	-
RRB31W15G7R-STW	○	○	-	○	-	-	-	-	-	-	-	-	○	-	-
RRB71AWB1RX3-SL	-	-	-	-	-	-	○	-	-	-	-	-	-	-	-
RRB71W15G11R-STW	○	○	-	○	-	-	-	-	-	-	-	-	○	-	-
RRB71W15G23R-STW	○	○	-	○	-	-	-	-	-	-	-	-	○	-	-
RRB71W15G7R-STW	○	○	-	○	-	-	-	-	-	-	-	-	○	-	-
RRB71W15G7V-STW	○	○	-	○	-	-	-	-	-	-	-	-	○	-	-
RRB71W5ALRSR	○	-	○	○	-	-	-	-	-	-	-	○	-	-	-
RRB31W18G28R-STW	○	○	-	○	○	-	-	-	-	-	-	-	-	-	-
RRB71W18G28R-STW	○	○	-	○	○	-	-	-	-	-	-	-	-	-	-



グリル用調理容器対応表 - ビルトインタイプリンナイ製(RRシリーズ)ガスコンロをお使いの方
お手持ちのコンロ製品型番 先頭の英数字を下記からお調べください。対応するグリル用調理容器をご確認いただけます。

コンロ型番	浅型プレート											深型鍋			
	グリル用プレート									ココット		ダッチオーブン		ココット ダッチオーブン	
コンロ型番	RCP-71W	RCP-73V	RCP-72V	RCP-74W	RCP-80W	RCP-81W	RCP-65V	RCP-48V	RCP-60M	RBO-C1V	RBO-C2V	RDH-01V	RDH-02V	RBO-D1V	RBO-D2V
RRB71W15G23R3-STW	○	○	-	○	○	-	-	-	-	○	-	-	-	○	-
RRB71W18G28R5-STW	○	○	-	○	○	-	-	-	-	-	-	-	-	-	-
RRB31W15G7R3-STW	○	○	-	○	○	-	-	-	-	○	-	-	-	○	-
RRB31W15G23R3-STW	○	○	-	○	○	-	-	-	-	○	-	-	-	○	-
RRB71W15G7R3-STW	○	○	-	○	○	-	-	-	-	○	-	-	-	○	-
RRB71W15G7V3-STW	○	○	-	○	○	-	-	-	-	○	-	-	-	○	-
RRB71W15G7R5-STW	○	○	-	○	○	-	-	-	-	○	-	-	-	○	-
RRB31W18G28R5-STW	○	○	-	○	○	-	-	-	-	-	-	-	-	-	-
RRB31W15G7R5-STW	-	-	-	○	○	-	-	-	-	○	-	-	-	○	-