



**グリル用調理容器対応表** - ビルトインタイプリンナイ製(RXシリーズ)ガスコンロをお使いの方  
 お手持ちのコンロ製品型番 先頭の英数字を下記からお調べください。対応するグリル用調理容器をご確認いただけます。

コンロ型番	浅型プレート											深型鍋			
	グリル用プレート											ダッチオーブン		ココット ダッチオーブン	
	RCP-71W	RCP-73V	RCP-72V	RCP-74W	RCP-80W	RCP-81W	RCP-65V	RCP-48V	RCP-60M	RBO-C1V	RBO-C2V	RDH-01V	RDH-02V	RBO-D1V	RBO-D2V
RX31M2H2R-VL	-	-	-	-	-	-	-	-	○	-	-	-	-	-	-
RX31M2H2R-VR	-	-	-	-	-	-	-	-	○	-	-	-	-	-	-
RX31M2H2S-BL	-	-	-	-	-	-	-	-	○	-	-	-	-	-	-
RX31M2K1R-BL	-	-	-	-	-	-	-	-	○	-	-	-	-	-	-
RX31M2K1R-BR	-	-	-	-	-	-	-	-	○	-	-	-	-	-	-
RX31M3H2RL	-	-	-	-	-	-	-	-	○	-	-	-	-	-	-
RX31M3H2RR	-	-	-	-	-	-	-	-	○	-	-	-	-	-	-
RX31W8B11R-BL	-	-	-	-	-	-	○	-	-	-	-	-	-	-	-
RX31W8B11R-BR	-	-	-	-	-	-	○	-	-	-	-	-	-	-	-
RX38MK2RSL	-	-	-	-	-	-	-	-	○	-	-	-	-	-	-
RX38MK2RSR	-	-	-	-	-	-	-	-	○	-	-	-	-	-	-
RX38W7K9R-VL	-	-	-	-	-	-	○	-	-	-	-	-	-	-	-
RX38W7K9R-VR	-	-	-	-	-	-	○	-	-	-	-	-	-	-	-
RX31W13A18RW	-	-	-	-	-	-	○	-	-	-	-	-	-	-	-
RX31W13K12RW	-	-	-	-	-	-	○	-	-	-	-	-	-	-	-
RX31W8K12R-VL(RS31W8)	-	-	-	-	-	-	○	-	-	-	-	-	-	-	-
RX31WG13RX3L	-	-	-	-	-	-	○	-	-	-	-	-	-	-	-
RX38W3A2RSL(RS38W3A2)	-	-	-	-	-	-	○	-	-	-	-	-	-	-	-
RX38W3K1RBL(RS38W3K1)	-	-	-	-	-	-	○	-	-	-	-	-	-	-	-
RX71W13A18DXL(71W13A)	-	-	-	-	-	-	○	-	-	-	-	-	-	-	-
RX71W8A2R-VL(RS71W8A)	-	-	-	-	-	-	○	-	-	-	-	-	-	-	-
RXE38W2B1RSL(W2B1RSL)	-	-	-	-	-	-	○	-	-	-	-	-	-	-	-
RXE38W3K1RSL(W3K1RSL)	-	-	-	-	-	-	○	-	-	-	-	-	-	-	-
RXE78W2A2RSL(W2A2RSL)	-	-	-	-	-	-	○	-	-	-	-	-	-	-	-
RXE-N38M5GT-STL	-	-	-	-	-	-	-	-	○	-	-	-	-	-	-
RXE-N38W5GTA-STL	-	-	-	-	-	-	○	-	-	-	-	-	-	-	-
RXE-N38WA-SBL(N38W5G)	-	-	-	-	-	-	○	-	-	-	-	-	-	-	-
RXE-N78W5GTA-STL	-	-	-	-	-	-	○	-	-	-	-	-	-	-	-
RX-N38MGTB-L(M5GSH)	-	-	-	-	-	-	-	-	○	-	-	-	-	-	-
RX-N38MGT-STL(M5GS3H)	-	-	-	-	-	-	-	-	○	-	-	-	-	-	-
RX-N78WGT-STL(W5GS1X)	-	-	-	-	-	-	-	○	-	-	-	-	-	-	-
RX31W20A31DW	-	-	-	-	-	○	○	-	-	-	-	-	-	-	-
RX31W20B32DW	-	-	-	-	-	○	○	-	-	-	-	-	-	-	-
RX71W20A31DW	-	-	-	-	-	○	○	-	-	-	-	-	-	-	-
RX31M4H2RW	-	-	-	-	-	-	-	-	○	-	-	-	-	-	-
RX31W20K15DW	-	-	-	-	-	○	○	-	-	-	-	-	-	-	-
RX31W21A18RW	-	-	-	-	-	-	○	-	-	-	-	-	-	-	-